


# Steering Gear Alarm System

# AL-101

## Maunual



# **AL101 Steering Gear Alarm System**

Chapter 0 – Dip Switch factory default

Chapter 1 - Operation ECR / FWD / AFT / VDR  
Description keypad  
Description lamp

Chapter 2 - Dimension of AL101 series ECR / FWD / AFT / VDR

Chapter 3 –Input & Output signal terminal of  
AL101 ECR / FWD / AFT /VDR

Chapter 4 – Test flow of AL101

## Chapter 0

# **Factory Default**

### 1. ECR / FWD / AFT

#### 1.1 Dip Switch

Switch	ON	OFF	Default
1	Operation Mode	Test Mode	ON
2	DC ON lamp blink (Red / Green)	DC ON lamp ON (Red)	ON
3	Full Relay output Mode	Half relay output Mode	ON
4	NC	NC	-
5	NC	NC	-
6	Firmware download	Normal mode	OFF

1.2 Resistor Termination ON/OFF switch: OFF

### 2. VDR

#### 2.1 Dip Switch

Switch	ON	OFF	Default
1	Operation Mode	Test Mode	ON
2	Full Relay output Mode	Half relay output Mode	ON
3	NC	NC	-
4	NC	NC	-
5	NC	NC	-
6	Firmware download	Normal mode	ON

2.2 Resistor Termination ON/OFF switch: OFF

## **CAUTION!**

\*ECR / FWD / AFT Relay output mode(Full / Half) run independently.

# **AL101 Steering Gear Alarm System**

## Chapter 1

# ECR / FWD / AFT / VDR Operation

AL101 Steering Gear Alarm System  
ECR / FWD / AFT / VDR

General Specification


- Voltage: DC 24V
- Current: 1.6A(38A)
- Communication: CAN BUS / RS485 / NMEA018(RS422)

Features

- Compact size, with easy access to wiring on rear connector.
- 4 wires CAN BUS data transmission
- Software utilizing 20 years experiences in control system
- Big square dial keypad for easy access to function button
- Self-test, feed-back system internal utilizing.
- NMEA0183 protocol available with AL101-VDR unit.
- DIMMER Key available to adjust L.E.D brightness(5 step)
- Permanent and durable L.E.D implement
- Low current power and high brightness L.E.D built in back light
- Monitoring system optimization on comfortable display
- Monitor SGR DC supply
- PUMP RUN relay output available
- Autopilot Fail Alarm connection

# System Configuration

## Single Station / Double Steering Gear Alarm





## CAUTION!

ECR to FWD are the main line RxTx unit, meaning wiring **MUST** be firstly from ECR to FWD then to either AFT to VDR or vice versa or anyone. If FWD to AFT data line is broken then ECR to FWD will still be operational.

Frontal Face

AL101-ECR




# AL101-FWD






AL101-AFT



# AL101-VDR



## Description of AL101-ECR/FWD/AFT/VDR Keypad

### 1) SILENCE Key



This key able to maintain to each lamp's activation or deactivation  
After buzzer has activation, this key able to stop to buzzer sound

## **CAUTION!**

If setting Dip Switch "2" setting done ON, relay output will be working full mode.  
Meanwhile if setting Dip switch "2" OFF relay output will be working half mode

### 2) RESET Key



This key able to re-boot to all lamp's activation and deactivation.  
Press this key then press SILENCE Key again to maintain to each  
lamp's activation and deactivation. Or check buzzer sound activation

### 3) LAMP TEST Key



This key able to all LAMP ON even each lamp has activation or deactivation  
This key check to LAMP itself working.  
If on pressing this key both of activation and deactivation lamp ON at once.  
Then if release this key the deactivation lamp will be OFF

### 4) DIMMER Key



This key able to adjust to LAMP brightness  
Brightness has total 5 steps.

## Description of AL101-ECR/FWD/AFT LAMP

1) **FU FAIL LAMP**

Input signal “1” second later LAMP activate

2) **PUMP HYDR. LOCK LAMP**

Input signal “1” second later LAMP activate

3) **PHASE FAIL LAMP**

Input signal “2” second later LAMP activate

4) **PUMP LOW OIL LEVEL LAMP**

Input signal “3” second later LAMP activate

5) **DC ON LAMP**

Depend on input signal LAMP will be activate to “RED” or “GREEN”  
(Please see the chapter 3 Input & output signal terminal)

## **CAUTION!**



Except above FU FAIL / PUMP HYDR. LOCK / PHASE FAIL / PUMP LOW OIL LEVEL these “4” kind LAMP, the other LAMP will be activate once it has input signal.

# **AL101 Steering Gear Alarm System**



## Chapter 2

# ECR / FWD / AFT Dimension

ECR / FWD / AFT



# VDR






# **AL101 Steering Gear Alarm System**


Chapter 3

**ECR / FWD / AFT / VDR  
Input & output signal terminal**


## ECR input & output signal terminal




# FWD input & output signal terminal



## AFT input & output signal terminal



# VDR output signal terminal



# **AL101 Steering Gear Alarm System**

## Chapter 4

# Test flow

#### 4.1 Purpose

: This alarm testing procedure is to check and confirm that the alarm system is working and meet the design requirement.

#### 4.2 Testing Procedure

4.2.1 Connect the FWD, AFT & ECR panel as single line drawing.

4.2.2 Connect ECR panel to external alarm signals. The alarm signal can be turned off And on by a toggle switch. The signal is +24V DC. Put the switches in off position for all the alarm signals before testing.

4.3 Lamp test: Press the lamp test button, all the lamps on the panel should be on.

4.4 Dimmer test: When the lamp test button is pressed, press the dimmer button and the brightness will change accordingly.

#### 4.5 Individual alarms and indications test

##### DC ON

Step 1: Provide +24V DC at the FWD alarm panel input terminal P+.

Step 2: DC ON indicator Green light is on at port side for all the panels.

Step 3: No alarm activated.

Step 4: Provide +24VDC at the FWD alarm panel input terminal S+

Step 5: DC ON indicator Green light is on at STBD side for all the panels.

Step 6: No alarm activated.

Step 7: Remove the input signal at P+ or S+.

Step 8: The indicator light color changes to Red and alarm activated.

Step 9: check output signal to other equipment at ECR panel when alarm activated

##### AUTOPILOT FAIL

Step 1: Close AUTOPILOT FAIL contact at the FWD panel input.

Step 2: Autopilot fail indicator Red light is blinking for all the panels.

Step 3: Buzzer sound.

Step 4: Press the Silence button, the autopilot fail indicator light is steady in Red and Buzzer is off.

Step 5: Press the alarm reset button, the buzzer sound again and indicator is blinking again

Step 6: Repeat Step 4.

Step 7: Cut off the AUTOPILOT FAIL contact, the autopilot fail indicator is still on

Step 8: Press alarm reset button again, the Autopilot alarm indicator light off.

Step 9: Check out signal to other equipment at ECT panel when alarm activated.

##### FU FAIL

Step 1: Close FU FAIL contact at the FWD panel input

Step 2: FU FAIL indicator light is blinking for all the panels.

Step 3: Buzzer sound.

Step 4: Press the silence button, the FU FAIL indicator light is steady and buzzer is off.

Step 5: Press the alarm reset button, the buzzer sound again and indication is blinking

Step 6: Repeat Step 4 .

Step 7: Cut off the FU FAIL contact, the autopilot fail indicator is still on.

Step 8: Press alarm reset button again, the alarm indicator light off

Step 9: Check out signal to other equipment at ECR panel when alarm activated

##### PUMP 1 RUN

- Step 1: Close PUMP 1 RUN switch
- Step 2: PUMP 1 RUN indicator light ON
- Step 3: Buzzer not on.
- Step 4: Open the PUMP 1 RUN switch
- Step 5: Indicator light off

#### PUMP 1 STOP

- Step 1: Close PUMP 1 STOP switch
- Step 2: PUMP 1 STOP indicator light on
- Step 3: Buzzer not on.
- Step 4: Open the PUMP 1 STOP switch
- Step 5: Indicator light off

#### PUMP 2 RUN & STOP

-To repeat PUMP 1 RUN & STOP test.

#### POWER 1 FAIL

- Step 1: Provide + 24V DC to the ECR input terminal at P4A
- Step 2: POWER 1 FAIL indicator light is blinking for all the panels.
- Step 3: Buzzer sound.
- Step 4: Press the silence button, the POWER 1 FAIL indicator light is steady and buzzer is off
- Step 5: Press the alarm reset button, the buzzer sound again and indicator is blinking again
- Step 6: Repeat Step 4.
- Step 7: Stop supply +24V DC to the terminal input, the power 1 fail indicator is still on.
- Step 8: Press alarm reset button again, the alarm indicator light off.
- Step 9: Check out signal to other equipment at ECR panel when alarm activated.

\*All the other alarm testing has the same testing procedure as POWER 1 FAIL testing Procedure.

#### **TIME DELAY TEST**

- LOW OIL LEVEL : **3 second**
- HYDRAULC LOCK: **1 second**
- PHASE FAIL: **2 second**
- FU FAIL: **1 second**

\*The testing steps are same as POWER 1 FAIL.

- Step 1: Provide alarm input signal to the respect alarm input terminal.
- Step 2: Count the time between signal input and alarm activate.
- Step 3: Compare the time between the setting an count.
- Step 4: The time delay setting and count should follow the setting time

#### 4.6 Testing for signal output to other equipment



#### FWD & AFT alarm panel relay Signal output

	Input Signal	Input Location	Output Signal (FWD & AFT panels)	Output Qty Each Panel	Remark
PORT	PUMP 1 RUN	ECR	+24VDC	1	No alarm
	PUMP 1 STOP	ECR	+24VDC	1	No alarm
	PUMP 2 RUN	ECR	+24VDC	1	No alarm
	PUMP 2 STOP	ECR	+24VDC	1	No alarm
STBD	PUMP 1 RUN	ECR	+24VDC	1	No alarm
	PUMP 1 STOP	ECR	+24VDC	1	No alarm
	PUMP 2 RUN	ECR	+24VDC	1	No alarm
	PUMP 2 STOP	ECR	+24VDC	1	No alarm
PORT	PUMP 1 or PUMP 2 RUN	ECR	+24VDC	2	No alarm
STBD	PUMP 1 or PUMP 2 RUN	ECR	+24VDC	2	No alarm
PORT	PUMP 1 & PUMP 2 RUN	ECR	+24VDC	3	No alarm
STBD	PUMP 1 & PUMP 2 RUN	ECR	+24VDC	3	No alarm

#### 4.7 Testing for signals output to VDR

Every indicator light will have a respect +24V DC output at VDR option or data output for NMEA protocol option.

## WARRANTEE CERTIFICATION

This product is passed “Sewhacnm”’s strict quality test.

If there is defect of manufacturing or abnormal detection within warrantee period, please contact our Agent or Distributor with this Warrantee Certification.

## WARRANTEE CLAUSE

**1. The Warrantee period, we can guarantee, is one(1) year from your purchasing date**

**2. Warrantee Exception Clause**

- Warrantee period is expired.
- Any kinds of Mal-function or defection caused by Modification or Repair without Sewhacnm’s permission.
- Any kinds of Mal-function, Defection, or External damage, caused by operator
- Any kinds of Mal-function, Defection, caused by using spare part from Non-Authorized Distributor or Agent.
- Any kinds of Mal-function, Defection, caused by not following Warnings or Cautions mentioned on this manual.
- Any kinds of Mal-function, Defection caused by “Force Majeur”, like Fire, Flood.
- Without presentation of this “Warrantee Certification”.

**3. Other**

- Any kinds of “Warrantee Certification” without authorized Signature is out of validity

<p style="text-align: center;"><b>Manufacturer</b></p> <p><b>Manufacturer : SEWHACNM Co.,Ltd.</b>                  #504, 302Dong, 397, Seokcheon-ro, Ojeong-gu,                  Bucheon-si, Gyeonggi-do, Korea                  Tel : +82 70) 4754 6140                  Fax : +82 32) 624 0065                  sales@sewhacnm.co.kr                  http://www.sewhacnm.co.kr  <b>Made in KOREA</b></p>	<b>Product</b>	AL101 Steering Gear Alarm System
	<b>Model</b>	ECR / FWD / AFT / VDR
	<b>AUTHORIZED SIGNATURE</b>	